

RETURN TO GOV. DOC. CLERK

DEPARTMENT OF THE ARMY TECHNICAL M

**PERATOR, ORGANIZATIONAL, DIRECT SUPPORT,
GENERAL SUPPORT, AND DEPOT
MAINTENANCE MANUAL**

**KETTLE, HEATING, BITUMINOUS,
GASOLINE ENGINE, WHEEL MOUNTED,
2 PNEUMATIC TIRES,
165-GALLON CAPACITY
(WHITE MFG. MODEL F3M-1)
FSN 3895-442-9741**

This copy is a reprint which includes current
pages from Changes 1 and 3.

SAFETY PRECAUTIONS

Do not use a lifting device of less than a 2,000-pound capacity. Do not allow the heating kettle to swing back and forth when it is suspended. Failure to observe this warning can result in damage to the equipment or injury or death to personnel.

Always release the pressure from the burner fuel tank before attempting to remove the cap. Do not touch the cap from cap when releasing pressure. Do not use a carbon tetrachloride-type fire extinguisher on a bitumen liquid fire. Failure to observe this warning will cause explosions injurious to personnel.

Always provide a metal-to-metal contact between the fuel container and the engine fuel tank when refueling. This will prevent a spark from being generated as the fuel flows over the metal surfaces.

Do not fill the engine fuel tank while the engine is in operation. Gasoline spilled on a hot engine can catch fire and explode, causing serious injury to personnel.

Do not attempt repairs on the power spray system while the engine is in operation.

Do not operate the heating kettle with the melting tank cover open during rain. Water contact with the melting tank near or at operating temperature will cause explosions injurious to personnel.

Change }
No. 3 }

HEADQUARTERS
DEPARTMENT OF THE ARMY
Washington, D. C., 17 Sept 1969

**Operator, Organizational, Direct Support
General Support, and Depot Maintenance
Manual
KETTLE, HEATING, BITUMINOUS: GASOLINE ENGINE;
WHEEL MOUNTED, 2 PNEUMATIC TIRES;
165-GALLON CAPACITY
(WHITE MFG. MODEL F3M-1) FSN 3895-442-9741**

TM 5-3895-334-15, 29 April 1970 is changed as follows:

Inside Front Cover "FSN 4210-984-5270" is changed to read "FSN 4210-889-2221."

Page i. Appendix B title is changed as follows: "BASIC ISSUE ITEM LIST AND ITEMS TROOP INSTALLED OR AUTHORIZED. "

Page 2-1. Paragraph 2-2 is superseded as follows:

- (5) Valve wrench
- (6) Manual burner fuel hose
- (7) Pressure gauge
- (8) Safety valve
- (9) Burner handle
- (10) Starter rope
- (11) Spray bar assembly with 2 pieces
- (12) Spray bar house assembly, 15 ft lg

2-2. Installation of Separately Packed Parts and Accessories

a. The following items have been removed prior to shipment and are packed inside the kettle.
Install as shown by Figure 2-1.

- (1) Drawoff valve
- (2) Thermometer
- (3) Torch
- (4) Burner cleaning wire

b. The fire extinguisher will be installed as follows:
(1) Bolt the fire extinguisher bracket mounting plate located on the left front of the kettle (observed from the towed end) with 4 #10 machine screws 1 inch long with nut washers are required for mounting.

(2) Place fire extinguisher in the bracket and fasten clamp.

Page B-1. Appendix B, Basic Issue Items, is superseded as follows:

and which must be turned in with the end item.

Items Troop Installed or Authorized List —

Section III. A list, in alphabetical sequence of items which at the discretion of the unit commander will accompany the end item, but are NOT subject to be turned in with the end item.

Explanation of Columns

The following provides an explanation of columns in the tabular list of Basic Issue Items List, Section III and Items Troop Installed or Authorized, Section III.

Source, Maintenance and Recoverability Code (SMR):

(1) Source code, indicates the source for the end item, Source codes are:

Explanation

Repair parts, special tools and test equipment supplied from GSA/DSA Or Army supply system and authorized for use at indicated maintenance levels.

Repair parts, special tools and test equipment which are procured and stocked for insurance purposes because the combat or military essentiality of the end item dictates that a minimum quantity be available in the supply system.

(2) Maintenance code, indicates the lowest level maintenance authorized to install the listed item. maintenance level code is:

Explanation

Crew/Operator

(3) Recoverability code, indicates whether un-recoverable items should be returned for recovery

S

ponents), special tools and test equipment which are considered economically feasible at direct and general support maintenance levels.

Repair parts, special tools, test equipment assemblies which are economically feasible at GSC and GSU activities and are normally furnished by supply on a change basis.

b. Federal stock Number. This column indicates the Federal stock number assigned to the item which will be used for requisitioning purposes.

c. Description. This column indicates the item name and any additional description of the item required.

d. Unit of Measure (U/M). A 2-character alphabetic abbreviation indicating the amount or quantity of the item upon which the allowance is based e.g., ft, ea, pr, etc.

e. Quantity Furnished with Equipment (Only). This column indicates the quantity of the item furnished with the equipment.

f. Quantity Authorized (Items Troop Installed or Authorized Only). This column indicates the quantity of the item authorized to be used with the equipment.

g. Illustration (BIIL Only). This column is divided as follows:

(1) Figure Number. Indicates the figure number of the illustration in which the item is shown.

(2) Item Number. Indicates the callout number used to reference the item in the illustration.

Section II. BASIC ISSUE ITEMS LIST

(1) SMR code	(2) Federal stock number	(3) Description	(4) Unit of meas	(5) Qty Furn with equip	(6) Illustration	
					(a) Figure No.	(b) Item No.
		Ref No. & mfr code	Usable on code			

	4210-889-2221	EXTINGUISHER, FIRE	EA
	5120-261-3793	WRENCH, ADJUSTABLE	EA
	5120-277-1461	WRENCH, PIPE	EA
	5120-262-8486	WRENCH, BUNG	EA
	8415-427-5003	GLOVES, CLOTH ASBESTOS	PR

Order of the Secretary of the Army:

CREIGHTON W
General, United
Chief of Staff

ficial:

VERNE L. BOWERS

Major General, United States Army

The Adjutant General

istribution:

To be distributed in accordance with DA Form 12-25B (qty rqr block No. 422) organizational maintenance requirements.
ituminous.

**Operator, Organizational, Direct Support,
 General Support, and Depot Maintenance Manual**

**KETTLE, HEATING, BITUMINOUS, GASOLINE ENGINE, WHEEL
 MOUNTED, 2 PNEUMATIC TIRES, 165-GALLON CAPACITY
 (WHITE MFG. MODEL F3M-1) FSN 3895-442-9741**

16-3895-334-15, 29 April 1970, is changed as follows:

front cover. Add: "Do not tow the kettle with the melt tank cover open. Vehicle motion can cause bitumen to splash out and burn personnel in the immediate vicinity." "Do not operate this equipment unless fire extinguisher, FSN 4210-984-5270, equivalent is readily available at all times."

Page 2-9. After paragraph 2-11a(6), add:

"CAUTION

Do not operate this equipment unless fire extinguisher, FSN 4210-257-5343, or equivalent is readily available at all times."

Page 2-12. After paragraph 2-11c(4), add:

"WARNING

Do not tow kettle with the melt tank cover open. Vehicle motion can cause bitumen to

Page 2-12, figure 2-6; add the following:

"NOTE

Both valves should be in center position."

Page 2-31, figure 2-6; add the following:

"NOTE

Upper valve should be in far left position. Lower valve in center position."

Page 2-14, figure 2-6; add the following:

"NOTE


Upper valve should be in center position. Lower valve in far left position."


Page 2-15, figure 2-6; add the following:

"NOTE

Both valves should be in far left position."

- Lockwasher
- Clamp
- Clamp
- Clamp
- Engine
- Fuel line
- Nut
- Lockwasher
- Brace
- Nut
- Lockwasher
- Vibration mount
- Capscrew
- Mount
- Nut
- Lockwasher
- Nut
- Lockwasher
- Flat washer
- Vibration mount
- Capscrew
- Lockwasher
- Cap screw
- Flat washer
- Strap
- Fuel tank
- Tank attaching strip
- Cap
- Elbow





7. Packing ring (2)
 8. Bypass nut
 9. Locknut
 10. Adjusting screw

13. Steel ball
 14. Cover screw
 15. Lubricating fitting
 16. Cover

19. Drive shaft
 20. Idler shaft
 21. Pump gear
 22. Drive shaft

Section II. BASIC ISSUE ITEMS

(1)	(2)	(3)		(4)	(5)
SMR Code	Federal stock No.	Ref No. & Mfr Code	Description	Usable on code	Unit of meas
			GROUP 01 ACCESSORIES		
PC	7510-889-3494		BINDER, looseleaf		ea
PC	7520-559-9618		CASE, operator and maintenance publications		ea
PC	4530-478-8073		CLEANER, jet burner TK-002 (03742)		ea
PC	4530-478-8074		TORCH, burner lighter TK-166B (03742)		ea
			GROUP 02--PUBLICATIONS		
			ARMY TECHNICAL MANUAL		
			TM 5-2805-256-14		ea
			TM 5-3895-334-15		ea
			ARMY LUBRICATION ORDER		
			LO 5-2805-256-12		ea
			LO 5-3895-334-12		ea

al:
ERNE L. BOWERS,
Major General, United States Army,
ne Adjutant General.

Chief of Staff.

tribution:

To be distributed in accordance with DA Form 12-25 (qty rqr block No. 421) operator maintenance requirements.
Bituminous.

**OPERATOR, ORGANIZATIONAL, DIRECT SUPPORT, GENERAL
SUPPORT, AND DEPOT MAINTENANCE MANUAL**

**KETTLE, HEATING, BITUMINOUS, GASOLINE ENGINE, WHEEL MOUNTED
PNEUMATIC TIRES, 165-GALLON CAPACITY (WHITE MFG. MODEL F3M)
FSN 3895-442-9741**

	Paragraph	Page
LIST OF CONTENTS		
Chapter 1. INTRODUCTION		
Section I. General	1-1, 1-2	1-1
Section II. Description and data	1-3—1-6	1-1
Chapter 2. INSTALLATION AND OPERATING INSTRUCTIONS		
Section I. Service upon receipt of equipment	2-1, 2-3	2-1
Section II. Movement to a new worksite	2-4, 2-5	2-4
Section III. Controls and instruments	2-6, 2-7	2-4
Section IV. Operation under usual conditions	2-8—2-11	2-8
Section V. Operation under unusual conditions	2-12—2-17	2-1
Chapter 3. OPERATOR AND ORGANIZATIONAL MAINTENANCE INSTRUCTIONS		
Section I. Operator and organizational maintenance tools and equipment	3-1, 3-2	3-1
Section II. Lubrication	3-3, 3-4	3-1
Section III. Preventive maintenance checks and services	3-5, 3-6	3-2
Section IV. Operator maintenance	3-7—3-19	3-5
Section V. Troubleshooting	3-20	3-5
Section VI. Field Expedient repairs	3-21	3-7
Section VII. Organizational maintenance procedures	3-22—3-35	3-8
Chapter 4. SHIPMENT AND LIMITED STORAGE AND DEMOLITION TO PREVENT ENEMY USE		
Section I. Shipment and limited storage	4-1—4-4	4-1
Section II. Demolition to prevent enemy use	4-5—4-9	4-2
Chapter 5. DIRECT SUPPORT, GENERAL SUPPORT, AND		

1-1	Rear three-quarter view of heating kettle
1-2	Schematic wiring diagram
2-1	Separately packed accessories, install as shown (sheet 1 of 2)
2-1	Separately packed accessories, install as shown (sheet 2 of 2)
2-2	Operating controls (sheet 1 of 3)
2-2	Operating controls (sheet 2 of 3)
2-2	Operating controls (sheet 3 of 3)
2-3	Reading range of instruments
2-4	Burner system startup
2-5	Engine pump cover
2-6	Bitumen flow chart (sheet 1 of 4)
2-6	Bitumen flow chart (sheet 2 of 4)
2-6	Bitumen flow chart (sheet 3 of 4)
2-6	Bitumen flow chart (sheet 4 of 4)
2-7	Motor spray component identification
2-8	Spray controls
3-1	Fuel system and engine, removal and installation
3-2	Blackout light, removal and installation
3-3	Tail, turn, and stoplight, removal, disassembly, installation and assembly
3-4	Wiring harness, removal and installation
3-5	Trailer coupling cable, removal and installation
3-6	Flexible coupling, removal, disassembly, installation and assembly
3-7	Gear reducer and clutch assembly, removal and installation
3-8	Clutch assembly, adjusting procedures
3-9	Kettle jacking procedures
3-10	Tire, tube, wheel removal
3-11	Hub, axle and spring, removal
3-12	Wheel bearing adjustment, and jack stand placement
3-13	Leg stands, removal and installation
3-14	Reflectors and thermometer, removal and installation
3-15	Piping, three-way valve, spray hose and pump, removal and installation (sheet 1 of 2)
3-15	Piping, three-way valve, spray hose and pump, removal and installation (sheet 2 of 2)
3-16	Pump, disassembly and reassembly
3-17	Pump pressure relief valve adjustment
3-18	Spray bar, assembly and disassembly
3-19	Fusible link, removal and installation
3-20	Air pump, shutoff valve, and line strainer, assembly and disassembly
3-21	Burner fuel line and thermal sensing element, assembly and disassembly
4-1	Placement of charges
5-1	Gear reducer, disassembly and reassembly
5-2	Clutch, assembly and disassembly
5-3	Melt tank, removal

Section I. GENERAL

ope

These instructions are published for the use of personnel to whom the Model F3M-1, Bitumen Heating Kettle is issued. They provide information on operation, lubrication, and daily preventive maintenance services of the equipment, accessories, parts, and attachments. Numbers placed in parentheses on illustrations in this manual indicate quantity.

1-2. Forms and Records

a. DA Forms and records used for equipment maintenance will be only those prescribed in this manual.

b. Report of errors, omissions, and recommendations for improving this publication by the actual user is encouraged. Reports should be submitted on DA Form 2028 (Recommended Change Recommendations) and forwarded direct to Commander, U.S. Army Mobility Equipment Center, ATTN: AMSME-MPP, 4300 Goodfellow St. Louis, Mo. 63120.


Section II. DESCRIPTION AND DATA


Description

General. Model F3M-1, Bitumen Heating Kettle (figs. 1-1 and 1-2) is a self-contained, weather-resistant, 5-gallon capacity, portable unit. It consists of a heating system, burner system, and power spray system and is wheel mounted. The power spray system is powered by a 1-cylinder Military Standard engine (fig. 1-2), Model 1A08-III. The unit is designed to heat, melt, and spray specified bituminous materials for the maintenance and repair of runways. The heating kettle is equipped to heat bituminous material in either liquid or solid

engine. For engine information, refer to TM 5-14.

d. *Burner System.* The burner system consists of a fuel tank, two burner fuel hose assemblies, two burners and a thermostatic control. It is designed for operation on kerosene or diesel fuel. The fuel tank (fig. 1-1) is equipped with a hand pump. Air pressure in the fuel tank forces fuel through both fuel line assemblies to the burners where it is vaporized, ignited, and the flames directed into the combustion chamber. One burner is manually controlled by means of a valve and equipped with a fuel hose so that it may be removed from its mounting bracket and used as a hand torch. The other burner is equipped with thermostatic control to maintain any desired temperature within the operating range. An overtemperature safety shut-off





HAND PUMP

ELECTRIC STARTER ENGINE

UPPER
3-WAY
VALVE

LOWER
3-WAY
VALVE

HAND SPRAY BAR

HT (2)

HT (3)

F

HD

directed back to the mixing tank or through the spray hose to the outlet nozzle. The pump assembly is equipped with a relief valve (fig. 3-17) that automatically allows material to circulate around the pump assembly when spraying operations are temporarily interrupted.

f. Trailer System. The trailer system consists of a frame assembly, running gear, and lighting system. It is equipped with tiedown eyes, lifting eyes, and towing eye (fig. 1-1) for coupling the unit to a towing vehicle. The lighting system operates when the power cable (fig. 1-1) is coupled to a power source.

1-4. Identification

The kettle has six identification plates. The data from these plates can be found in paragraph 1-6.

1-5. Difference in Models

This manual covers only the White Model F3M-1 Kettle. No known unit differences exist for this model.

1-6. Operational and Organizational Tabulated Data

a. General.

Manufacturer	White Mfg. Div. of Midwest Tank & Mfg. Co., Inc.
Model No.	F3M-1
Capacity	165 gal

b. Engine Plate. For engine plate data on model 1A08-III, see TM 5-2805-256-14.

c. Speed Reducer Plate.

Ratio	4.13 to 1
Service factor	1.00
Torque capacity	324 in.-lbs.

d. Air Tank Plate.

Manufacturer	Midwest Tank & Mfg. Co.
National Board No.	366
Max W. P.	100 psi
Tested	200 psi
Head thickness	3/16"
Shell thickness	3/16"
Year built	1969

e. Army Identification Plate.

Nomenclature	Kettle, Heat 165-gal Capacity
Model	F3M-1
Federal Stock No.	3895-442-974
Warranty	12 months
Contract No.	DSA700-69-0
Gross vehicle wt.	3000 lbs.
Shipping wt.	1800 lbs.
Length	126"
Height	72"
Width	78"
Cube	410

f. Transportation Data Plate.

Overall length	126"
Overall height	72"
Overall width	78"
Shipping cubage	410"
Shipping tonnage	11
Shipping weight	1800 lbs

g. Wiring Diagram. A wiring diagram is provided for maintenance of the electrical system.

h. Clutch Assembly.


Manufacturer	Twin Disc Corporation
Model	V-1035

i. Speed Reducer Assembly.

Manufacturer	Dodge Manufacturing Corporation
Model number	SR-16A

j. Pump Assembly.

Manufacturer	Oberdorfer Pump Co.
Model number	9000 BR



DEVICE LEGEND

- 1 BLACK OUT TAIL AND STOPLIGHT ASSEMBLY
- 2 BLACK OUT TAIL AND STOPLIGHT ASSEMBLY
- CABLE
- WIRING HARNESS
- 1 SERVICE TAIL, TURN, AND STOPLIGHT
- 2 SERVICE TAIL, TURN, AND STOPLIGHT

SYMBOL LEGEND



WIRE CONNECTOR

Section I. SERVICE UPON RECEIPT OF EQUIPMENT

Inspecting and Servicing Equipment

Remove protective covering or sealing material from valves, tank openings, etc.

Remove separately packed accessories and parts inside heating kettle.

Make visual inspection of the kettle and accessories for damage or missing parts.

Check equipment against packing list and report any discrepancies to field maintenance.

Installation of Separately Packed Parts and Accessories

The following items have been removed prior to shipment, and are packed inside the kettle. Install as shown by figure 2-1.

Drawoff valve.

Thermometer.

Torch.

d. Burner cleaning wire.

e. Valve wrench.

f. Manual burner fuel hose.

g. Pressure gauge.

h. Safety valve.

i. Burner handle.

j. Starter rope.

k. Spray bar assembly with 2 pieces.


l. Spray bar hose assembly, 15 ft lg.

2-3. Installation and Setting-Up Instructions

a. Lower front leg stand (fig. 1-1) and rear leg stand (fig. 1-2) and pin in place before releasing towing vehicle, or releasing tension on lifting cable.

b. Keep kettle as level as possible during operation.

c. Chock wheels, if necessary, to prevent unintentional movement.



BURNER
CLEANING


STARTER OFF

PERFORMANCE

DRAW OFF
VALVE

SPRAY BAR HOSE
ASSEMBLY 15 FT LG

SPRAY BAR ASSEMBLY



BURNER HANDLE

MANUAL BURNER
FUEL HOSE

- a. Attach towing eye (fig. 1-1) to suitable towing vehicle.
 - b. Connect power cable (fig. 1-1) to vehicle power receptacle.
 - c. Raise front leg stand (fig. 1-1) and rear leg stand (fig. 1-2) and pin in retracted position.
 - e. Attach safety chains to towing vehicle from kettle.
- 2-5. Re-installation After Movement**
See paragraph 2-3.

Section III. CONTROLS AND INSTRUMENTS

2-6. General

This section describes and illustrates the various controls and instruments and provides the operator with sufficient information to insure proper operation of the kettle under normal circumstances.

2-7. Controls and Instruments

Figure 2-2 illustrates and explains the function of the controls. Figure 2-3 illustrates the normal readings for all instruments.





Figure 2-2. Operating controls (sheet 1 of 3).



BURNER NEEDLE VALVE ASSEMBLY.
CONTROLS FUEL FLOW TO BURNER.







Figure 2-2. Operating controls (sheet 3 of 3).

150° TO 350° TEMPERATURE
CONTROL. REGULATES
MELT TEMPERATURE



THERMOMETER. INDICATES
MELT TEMPERATURE



15 PSI - 30 PSI AIR PRESSURE
GAUGE. GIVES FUEL TANK
AIR PRESSURE

The instructions in this section are published for information and guidance of personnel responsible for operation of the heating kettle.

It is essential that the operator know how to perform every operation of which the heating kettle is capable. Paragraphs 2-9, 2-10, and 2-11, give instructions on starting, stopping, and operating details of the engine and heating kettle. Since nearly every job presents a different problem, the operator must have to vary the given procedure to fit the individual job.

Engine Starting Instructions

Refer to paragraph 2-11d(8) for engine stopping instructions.

Engine Stopping Instructions

Refer to paragraph 2-11d(8) for engine stopping instructions.

Kettle Operating Instructions

Starting Instructions for Both Burners.

(1) Open stack cover (fig. 1-1). Fill burner fuel tank three-fourths full with clean kerosene or diesel kerosene preferred (fig. 2-4).

Caution: DO NOT FILL TANK OVER THREE-FOURTHS FULL. RESERVED SPACE REQUIRED FOR COMPRESSED AIR.

BURNER CONTROLS WILL NOT OPERATE PROPERLY UNLESS ADEQUATE VOLUME OF COMPRESSED AIR IS AVAILABLE IN TANK.

(2) Pressurize burner fuel tank with built-in pump, to approximately 25 p.s.i., then open the valve located at bottom of fuel tank (fig. 2-4).

(3) Open valve at burner, slightly, allow fuel to fill priming cup one-quarter full. Close valve and take hand torch and soak it with fuel. Now, light saturated torch and place it in priming cup to ignite fuel located there. Allow fuel to burn until flame is hot enough to vaporize fuel. Allow two or three minutes for vaporizing coil to heat. Priming cup must have to be refilled before coils are hot enough to vaporize fuel. When fuel is vaporized, reopen valve at burner one-eighth turn. If burner spits oil, close valve again and allow more time for gas to generate.

(4) Once burner stops spitting oil, reopen valve until burner gives smooth burning performance.

Note. Maintain air pressure in fuel tank between 20 and 30 p.s.i. for best burner performance.

(5) Set thermostatic controller to desired operating temperature by turning knob located at top of the temperature controller, clockwise (fig. 2-5).

(6) If operating heat chamber temperature rises above preset temperature by 15°, the controller will automatically depressurize fuel tank and flame will fail. When this happens, allow manifold to cool until it drops back past pre-set temperature. Then, repeat steps (1) thru (5) as may be required.




Figure 2-4. Burner system startup.

Operating Pumping System.

(1) Place levers on upper and lower three-way valves to circulate position (fig. 2-6, sheet 1).

(e) Close choke lever (fig. 2-2, sheet 1).

(f) Check clutch shifter to make sure disengaged (fig. 2-7).

HA
NOTE: BEFORE RUNNING ENGINE
SLIP CHAIN HOOK THROUGH
HASP SLOT TO HOLD COVER
DOOR FIRMLY IN PLACE

BEFORE START ENGINE


NOTE COVER

BEFORE START

THE

valves to spray position (fig. 2-6, sheet 2).
Place spray bar nozzles over open material
(2-8).
Open control valve on spray bar and allow

tank. You are now ready to commence spraying.
Note. If spraying is interrupted for more than two m
repeat procedures in (2) and (3), above.







Figure 2-6. Bitumen flow chart (sheet 2 of 4).



ME5-3895-334-1

Figure 2-6. Bitumen flow chart (sheet 3 of 4).





Figure 2-6. Bitumen flow chart (sheet 4 of 4).






Figure 2-8. Spray controls.

Heating Kettle Shutdown.

(5) Turn upper three-way valve to circulating position (fig. 2-6, sheet 1).

solvent to open side of lower three-way valve (fig. 2-6, sheets 3 and 4).

(6) Engage clutch: pump solvent through

Operation in Extreme Cold

Fuel. Keep fuel tanks as full as possible at all times to prevent condensation. Drain and service fuel strainer frequently (TM 5-2805-256-14).

Engine. During warmup, allow engine sufficient time to reach normal operating temperature before applying load.

Lubrication. Lubricate as specified in current lubrication order.

Pumping System. It may be necessary to heat valves and pump, with hand torch, to establish circulation through the piping system.

Operation in Extreme Heat

Cooling. Check cooling fins on the engine cylinder frequently to make sure they are clean and undamaged.

Lubrication. Lubricate as specified in current lubrication order.

Fuel. Keep fuel tanks as full as possible at all times to prevent condensation. Drain and service fuel strainer frequently (TM 5-2805-256-14).

Operation in Dusty or Sandy Areas

Air Cleaner. Refer to TM 5-2805-256-14 and service the air cleaner frequently to keep the engine free of dust and dirt.

Fuel. Strain all fuel before adding to the fuel tanks. Clean the area around the fuel tank cap assembly to prevent the entrance of dust and dirt during the filling operation.

c. Lubrication. Lubricate as specified in the current lubrication order.

2-15. Operation Under Rainy or Humid Conditions

a. General. If the unit is outside and not operating, place a canvas or other waterproof covering over the unit during storms.

Warning: DO NOT OPERATE THE MELTING KETTLE WITH THE MELTING COVER OPEN DURING RAIN. WATER IN CONTACT WITH BITUMEN NEAR OR AT COOLING TEMPERATURE WILL CAUSE EXPLOSIONS INJURIOUS TO PERSONNEL.

b. Fuel. Keep the fuel tanks as full as possible at all times to prevent condensation. Drain and service the fuel strainer frequently (TM 5-2805-256-14).

c. Lubrication. Lubricate as specified in the current lubrication order.

2-16. Operation in Salt Water Areas

a. General. Salt water causes corrosive action on metal. Care must be taken to avoid contact with salt water; wash the unit with clean, fresh water.

b. Preservation. Paint all exposed nonferrous surfaces. Coat exposed parts of polished steel or ferrous material with rustproofing material. Apply a light coat of grease.

2-17. Operation at High Altitudes

Refer to TM 5-2805-256-14 for engine operation at high altitude.

Section I. OPERATOR AND ORGANIZATIONAL MAINTENANCE TOOLS AND EQUIPMENT

Special Tools and Equipment

Special tool required to perform operator maintenance on the burner is listed in table 3-1. Reference illustration and the use of this tool are given in the table. The five-digit code preceding the

stock number is the Federal supply code, which identifies the manufacturer of the tool. No special training is required by organizational maintenance personnel in performing maintenance on the kettle.

Table 3-1. Special Tools

Item	FBN or part No.	Reference		Use
		Plat.	Para	
Cleaning needle.	(03742) TK-002	3-21	3-35	To clean burner orifices.

Organizational Maintenance Repair Parts

Organizational maintenance repair parts are listed and illustrated in TM 5-3895-334-25P.

Section II. LUBRICATION

General Lubrication Information

Refer to LO 5-2805-256-12 for lubrication of

Refer to LO 5-3895-334-12 for lubrication of
kettle.

place, away from heat. Allow no dirt, dust, or foreign material to mix with the lubricant at any time. Keep all lubrication equipment clean and ready for use.

b. *Cleaning.* Keep all external parts not in contact with lubrication clean from lubrication. After lubrication operation, remove any excess

Detailed Lubrication Information

General

To insure that the heating kettle is ready for operation at all times, it must be inspected systematically so that defects may be discovered and corrected before they result in serious damage or failure. Necessary preventive maintenance checks and services to be performed are listed as described in graph 3-6.

The item numbers indicate the sequence of minimum inspection requirements. Defects discovered during operation of the unit will be noted for future inspection, to be made as soon as operation has

ceased. Stop operation immediately if a defect is noted during operation which would damage equipment if operation were continued. All deficiencies and shortcomings will be recorded, and with the corrective action taken, on DA Form 1 (Equipment Inspection and Maintenance Worksheet) at the earliest possible opportunity.

3-6. Preventive Maintenance Checks and Services

Table 3-2 lists operator and organizational preventive maintenance checks and services.

Table 3-2. Preventive Maintenance Checks and Services

	Interval					Org.		Item to be inspected	Procedure	Reference
	Operator									
	Daily				M	Q				
	B	D	A	W						
	X						General visual inspection	Make a general visual inspection of the unit for cracks, breaks, loose or missing bolts, nuts, etc. See that engine is securely mounted and unit set as level as possible. Inspect for tampering, damage, fuel, or bitumen leaks. Do not operate until deficiencies are corrected.		
2	X				X	X	Lubrication	Lubricate in accordance with current lubrication order.		
3	X				X	X	Engine	For preventive maintenance instructions on engine, refer to TM 5-2805-256-14.	TM 5-2805-256-14	
4	X				X	X	Fuel tank and cap	Inspect fuel tank for insecure mounting and leaks. Inspect cap for defective gasket or insecure fit. Secure loose mountings. Replace leaking or damaged tank or cap.	Fig. 3-1	
5	X		X		X	X	Fuel lines	Inspect for damaged or leaking fuel line or fittings. Tighten loose fittings. Replace damaged lines.	Fig. 3-1	
6						X	Coupling	Inspect coupling for looseness or damaged setcrews, etc. Replace damaged	Para 3-24	

Daily				M	Q	Item to be inspected	Procedure	Reference
B	D	A	W					
					X	Valves	Inspect upper and lower 3-way valves for cracks, leaks, improper operation, and inadequate lubrication. Replace defective valves. Lubricate as described in the current lubrication order.	Para 3-22
					X	Coupling, spray bar assembly, piping and cock.	Inspect the pipe coupling for cracks or damage. Inspect the spray bar assembly for cracks, kinks, leaks, or other damage. Inspect spray bar cock for freedom of operation and leaks. Inspect spray nozzles for restrictions. Replace or repair damaged parts. Clean nozzles.	Para 3-30 fig. 3-3
			X		X	Burner fuel tank	Inspect fuel tank for loose mounting. Inspect cap for tight seal or damage. Inspect air pump for proper operation and damaged parts. Inspect pressure relief valve for damage & proper setting. Inspect pressure gage for proper operation and damage. Replace damaged fuel tank; secure loose mountings. Replace damaged air pump parts. Lubricate air pump. Replace defective pressure relief valve or pressure gage.	Para 3-30 fig. 3-2
					X	Burner fuel lines	Inspect fuel lines and fittings for damage or leaks. Clean filter and replace any damaged parts. Replace damaged fittings, hose or pipe. Tighten leaking connections.	Para 3-30 fig. 3-2
			X		X	Burner assemblies.	Remove and inspect burner strainer valve for dirt and damage. Inspect burner for cracks, breaks, or damage. Clean or replace strainer valve. Clean burner coils and jets. Replace damaged parts.	Para 3-30 fig. 3-2
					X	Thermostatic control	Inspect instrument for damage. Pressurize tank, turn temperature control knob counterclockwise to determine if valve opens to bleed off air pressure at approximately 15°F above ambient temperature.	Para 3-30 fig. 3-2
		X		X	X	Air lines	Inspect air line for leaks, or damaged parts. Inspect thermal element and capillary for damage. Replace damaged or malfunctioning instrument.	Fig. 3-20

Item Number	Operator				Org		Item to be inspected	Procedure	
	Daily				M	Q			
	B	D	A	W					
18						X	Leg stands	or looseness. Tighten or replace all loose or missing hardware. Straighten all minor dents. Report tracks, broken welds or misalignment to field maintenance. Report a defective tank to field maintenance. Repair or replace a damaged cover as necessary. Tighten or replace fusible link. Inspect front and rear leg stands for cracks, bends, and missing pins or chains. Repair or replace damaged leg stands. Replace missing or damaged pins and chains.	Fig. 3-
19						X	Springs and shackle bolts	Inspect the springs for misalignment, and shifted, bent, or broken leaves. Inspect for loose or missing hardware. Inspect all shackle bolts for damage. Tighten or replace all loose or missing hardware. Replace all defective springs or shackle bolts.	Para 3 fig.
20						X	Axle	Inspect the axle for loose or missing mounting hardware. Inspect the axle for bent condition. Tighten or replace all loose or missing hardware. Replace a defective axle.	Para 3 fig.
21				X		X	Wheels	Inspect the wheels for improper operating condition. Inspect for loose or missing mounting bolts and nuts. Inspect for defective grease seals. Tighten or replace all loose or missing mounting hardware. Replace a defective wheel or grease seal.	Para 3 fig.
22				X		X	Tires	Inspect the tires for improper air pressure, excessive cuts, and wear, embedded foreign material, and missing valve caps. Remove all foreign material. Inflate tires to 45 psi. Replace missing valve caps and defective tires.	Para 3 fig.
23						X	Lights and wiring.	Inspect the lamps for unserviceability. Inspect the line for dirt, breaks, or other damage. Inspect reflectors for discoloration, breakage, or insecure mounting. Inspect all wiring for defective installation, corroded or broken	Para 3 fig.

Daily				M	Q	Item to be inspected	Procedure	Reference
B	D	A	W					
					X	Appearance	Inspect the kettle for cleanliness, legibility of markings, and condition of paint. Correct all deficiencies or report them to field maintenance.	

Section IV. OPERATOR MAINTENANCE

Engine

o TM 5-2805-256-14.

Checks and Services

m the following inspections and services as

Fuel System

t fuel lines and fuel tank cap. If tank cap is defective, replace when needed.

Fuel Filters

t fuel filters for obstructions.

Electrical System

t tail and marker lamp assembly and trailer g cable for non-operation or surface damage.

Power Transfer

t vent plug on gear reducer. Inspect flexible g. Remove restrictions from vent plug.

Wheels and Track

t wheel assembly, tires and tubes. Service d tubes as needed.

Landings Gear, Leveling Jacks

leveling jacks for proper leveling when needed.

3-15. Gages (Non-Electrical)

Inspect thermometer and air pressure gage f readings.

3-16. Pumps

Inspect pressure relief valve. Adjust nut when needed. Service cone and collar shifter pump assembly as needed.

3-17. Fuel Tank (Burner)

Inspect safety valve assembly, air line, p fittings; adjust the pressure regulator as Service the fuel valve shutoff and fuel tank cap assembly as needed. Replace fill cap as needed.

3-18. Material Spray Bar

Inspect quick-action coupling and spray proper ease of operation. Service material s and spray nozzle for proper flow. Replace s zle as needed.

3-19. Material Piping and Accessories

Inspect fusible link, all piping and fittings. spect the quick-action couplings and spray h ice both upper and lower three-way valves melting vat.

quantity inadequate for preheating burner.

burner fails to ignite or stops burning.

burner flame insufficient or fluctuating

burner flame fails to reduce when
operating temperature is reached.

burner flame fails after operating
temperature is reached.

- a. Burner shutoff valve closed.
- b. Burner shutoff valve strainer clogged.
- c. Main fuel strainer clogged.
- d. Burner jet plugged.
- e. Fuel tank not pressurized.
- f. Water in fuel tank.
- g. Relief valve out of adjustment or defective.
- a. Burner jet plugged.
- b. Fuel tank pressure inadequate.
- c. Burner shutoff valve strainer clogged.
- d. Main fuel strainer clogged.
- e. Water in fuel tank.
- f. Burner coil excessively carboned.
- g. Thermostat setting below or at material temperature.
- a. Wrong or poor grade of fuel.
- b. Water in fuel tank.
- c. Fuel tank pressure low.
- d. Burner jet plugged.
- e. Burner coil excessively carboned.
- f. Fuel surge in line.
- g. Burner shutoff valve strainer clogged.
- a. Main fuel strainer clogged.
- a. Thermometer and thermostat are at opposite ends of melting tank. Heat may not be uniform throughout.
- b. Thermostat heat sensor defective or damaged.
- a. Burner shutoff valve partially closed.
- b. Fuel tank pressure low.
- c. Throttling valve not open sufficiently.

- a. Open burner shutoff valve.
- b. Remove and clean strainer screen (fig. 3-21).
- c. Remove and clean strainer screen (fig. 3-20) (para 3-35f).
- d. Clean jet (fig. 3-21) (para 3-17).
- e. Pressurize fuel tank to 25 psi (fig. 2-11a).
- f. Drain fuel tank, replenish fuel supply.
- g. *Adjust or replace relief valve (fig. 3-35b).
- a. Clean jet (fig. 3-20) (para 3-17).
- b. Pressurize fuel tank to 25 psi (fig. 2-11a).
- c. Remove and clean strainer screen (fig. 3-21) (para 3-35e).
- d. Remove and clean main strainer screen (fig. 3-20) (para 3-35f).
- e. Drain fuel tank, replenish fuel tank.
- f. *Remove burner and clean coils (fig. 3-35c).
- g. Set thermostat at desired operating temperature (fig. 2-4) (para 2-11a).
- a. Drain fuel tank and replenish fuel.
- b. Drain fuel tank and replenish fuel.
- c. Pressurize fuel tank to 25 psi (fig. 2-11a).
- d. Clean jet (fig. 3-21) (para 3-17).
- e. *Remove burner and clean coil (fig. 3-35c).
- f. Preheat the burner (fig. 2-4) (para 2-11a).
- g. Remove and clean strainer screen (fig. 3-21) (para 3-35e).
- h. Remove and clean main strainer screen (fig. 3-21) (para 3-35f).
- a. Circulate bitumen (fig. 2-6) (para 2-11a).
- b. *Replace thermal sensing element (fig. 3-21) (para 3-35g).
- a. Open burner shutoff valve.
- b. Pressurize fuel tank to 25 psi (fig. 2-11a).
- c. *Turn throttle valve adjusting screw clockwise, slowly, until desired results occur (fig. 2-4).

ing kettle smoke excessively black.

ometer indicates wrong
ature.

en material fails to flow from

p fails to operate or operates
rly.

th fails to operate or operates
rly.

reducer fails to operate.

ts fail to operate or operate
rly.

er does not track properly.

wear excessive.

- a. Improper preheating procedure.
- b. Burner flame fluctuates.
- c. Melted bitumen leaking into combustion chamber.
- a. Protective well covered by layer of carbon.
- b. Defective thermometer.
- a. Bitumen material not hot enough.
- b. Drain clogged.
- a. Bitumen material not hot enough.
- b. Cold bitumen material in line or valves.
- c. Bitumen level in melting tank below pump suction connection.
- d. Relief valve improperly adjusted or defective.
- e. Pump defective.
- a. Clutch out of adjustment.
- b. Clutch defective.
- Gear reducer damaged or defective.
- a. Lamp burned out.
- b. Loose connections.
- c. Ground lead loose or missing.
- d. Lamp assembly defective.
- e. Wiring harness damaged or defective.
- f. Trailer coupling cable damaged or defective.
- g. Towing vehicle electrical system defective.
- a. Tire pressure low.
- b. U-bolts loose or broken.
- c. Spring or center bolt broken.
- d. Shackle bolt loose missing, or broken.
- a. Loose hub bolts.
- b. Wheel bent.
- c. Axle bent.

- a. Refer to paragraph 2-11a.
- b. Refer to item 3, above.
- c. Inspect melting compartment for report leaks noted to DS maint.
- a. Clean protective well.
- b. Replace the thermometer.
- a. Heat to proper temperature.
- b. Clear drain by heating with heat gun.
- a. Heat to proper temperature.
- b. Warm lines, valves and pump with hand torch. Jog clutch and continue warming until pump runs free.
- c. Replenish melting kettle with bitumen to proper operating level.
- d. *Adjust the relief valve (fig. 3-16) (para 3-23b).
- e. *Replace pump (fig. 3-15) (para 3-23c).
- a. *Adjust clutch (fig. 3-8) (para 3-23d).
- b. *Replace clutch.
- *Replace gear reducer (fig. 3-7) (para 3-23e).
- a. *Replace lamp.
- b. *See that all ferrules are firmly seated in the proper sockets (wiring diagram fig. 1-3).
- c. *Tighten or replace ground lead (fig. 3-11) (para 3-23f).
- d. *Replace lamp assembly (fig. 3-12) (para 3-23g).
- e. Repair or replace wiring harness (fig. 3-4) (para 3-23h).
- f. *Replace cable (fig. 3-5) (para 3-23i).
- g. Report condition to operator of towing vehicle.
- a. *Inflate tires to 45 psi.
- b. *Tighten or replace U-bolts (fig. 3-9) (para 5-15).
- c. *Replace spring or center bolt (fig. 3-10) (para 5-15).
- d. *Tighten or replace shackle bolt (fig. 3-11) (para 3-7).
- a. *Tighten hub bolts (fig. 3-10) (para 5-15).
- b. *Replace wheel (fig. 3-10) (para 5-15).
- c. *Remove and straighten, or replace axle (fig. 3-11) (para 5-15).

at defective. Shut down automatic burner by closing valve at burner. Fire kettle with manually controlled burner.

TEMPERATURE.

Section VII. ORGANIZATIONAL MAINTENANCE PROCEDURES

Engine

Engine Maintenance. For operator and organizational maintenance of the engine, refer to TM 5-2805-4.

Engine Removal and Installation.

(1) Refer to figure 3-1 for fuel line and filter, removal and installation.

(2) Refer to figure 3-1 for engine, removal and installation. Refer to (8, fig. 3-6) for adaptor shaft removal and installation.

3-23. Electrical System

a. Refer to figure 3-2 for blackout light removal and installation.

b. Refer to figure 3-3 for tail, turn, stop assembly, removal and installation.


c. Refer to figures 3-2, 3-3, for bulb removal and installation.


d. Refer to figure 3-4 for wiring harness removal and installation.


e. Refer to figure 3-5 for trailer coupling removal and installation.


right-hand)
left-hand)
view

inline engine
view











b. Refer to figure 3-7 for clutch assembly, removal and installation.


(1) Refer to figure 3-8 for clutch assembly adjustment.

(2) Refer to figure 3-9 for clutch shifter, removal and installation.

(1) Refer to paragraph 3-24c for clutch cable, removal and installation.

(2) Refer to paragraph 3-24b for clutch cable, removal and installation.

(3) Refer to figure 3-7 for gear shifter, removal and installation.



ME5-3895-334-15/3-

Figure 3-6. Flexible coupling, removal, disassembly, installation and assembly.

STEP. 2

REMOVE SHIFTER

- A. REMOVE COTTER PIN (2)
- AND SLIDE ROD OUT
- B. LOOSEN BOLT AND SPREAD
- TO CLEAR COLLAR

STEP. 1

LOOSEN SETSCREW
AND MOVE TO PLACE

BOLT

STEP. 1


LOOSEN SETSCREW (2)
AND SLIDE BACK PLATE
AS FAR AS POSSIBLE

COTTER PIN

ROD


POINTS

ADJUST THE RIFLE STEEL APPROXIMATELY 3
LBS OF PRESSURE IS REQUIRED TO EXHAUST
CLUTCH. BEFORE ADJUSTING RING BY
TIGHTENING SCREW.



MF5-3895-334-15/3-8


Figure 3-8. Clutch assembly, adjusting procedures.




JACKING PROCEDURE:

1. PLACE LEG STANDS DOWN
2. PUT CHOCK BLOCKS DOWN TO PREVENT ROLLING
3. PLACE JACK UNDER AXLE BETWEEN WHEEL AND SPRING
4. JACK UNIT HIGH ENOUGH THAT TIRE CLEARS GROUND ABOUT AN INCH


TIRE




TUBE




FLAP




WHEEL



LUG NUT





KEY to figure 3-11:


1. Hub assembly
2. Grease cap
3. Spindle cotter pin
4. Spindle nut
5. Spindle washer
6. Outer cone bearing
7. Outer cup bearing
8. Grease seal
9. Inner cone bearing
10. Inner cup bearing
11. Wheel mtg hub
12. Wheel stud
13. Grease seal seat
14. U-bolt nut
15. Lockwasher
16. U-bolt
17. Clamp
18. Hexagon locknut
19. Hexagon head bolt
20. Cotter pin
21. Spring rivet
22. Axle
23. Leaf type spring


ME5-3895-334-1

Figure 3-11. Hub, axle and spring, removal.

move the wheel.
a. Refer to figure 3-11 for shackle bolt, removal and
tallation.


Refer to figure 3-14 for reflector, removal
and installation.





SLEEVE

NOTE: TIP FRONT OF KETTLE UP
FOR REMOVAL OF FRONT LEG
STAND. TIP FRONT OF KETTLE
DOWN TO REMOVE REAR LEG
STAND.




BOLT

NUT

LEG STAND

above the wheel.

b. Refer to figure 3-11 for shackle bolt, removal and installation.



FOR UPPER 3-WAY VALVE
REMOVAL LOOSEN UNIONS

SPRAY HOSE REMOVAL.
TAP QUICK COUPLING RING LIGHTLY TO
LOOSEN CONNECTION AND TWIST COUPLING
UNTIL IT COMES FREE & VALVE.

FOR UPPER 3-WAY VALVE
REMOVAL LOOSEN UNIONS




Figure 3-15. Piping, three-way valve, spray hose and pump, removal and installation (sheet 2 of 2).




Figure 3-16:

- 9. Pump
- 10. Pump head
- 11. Pump head cap screw
- 12. Pump head cap nut
- 13. Pump head cap washer
- 14. Pump head cap ring
- 15. Pump head cap nut
- 16. Pump head cap washer
- 17. Pump head cap ring
- 18. Pump head cap nut
- 19. Pump head cap washer
- 20. Pump head cap ring
- 21. Pump head cap nut
- 22. Pump head cap washer
- 23. Pump head cap ring
- 24. Pump head cap nut
- 25. Pump head cap washer
- 26. Pump head cap ring
- 27. Pump head cap nut
- 28. Pump head cap washer
- 29. Pump head cap ring
- 30. Pump head cap nut
- 31. Pump head cap washer
- 32. Pump head cap ring
- 33. Pump head cap nut
- 34. Pump head cap washer
- 35. Pump head cap ring
- 36. Pump head cap nut
- 37. Pump head cap washer
- 38. Pump head cap ring
- 39. Pump head cap nut
- 40. Pump head cap washer
- 41. Pump head cap ring
- 42. Pump head cap nut
- 43. Pump head cap washer
- 44. Pump head cap ring
- 45. Pump head cap nut
- 46. Pump head cap washer
- 47. Pump head cap ring
- 48. Pump head cap nut
- 49. Pump head cap washer
- 50. Pump head cap ring
- 51. Pump head cap nut
- 52. Pump head cap washer
- 53. Pump head cap ring
- 54. Pump head cap nut
- 55. Pump head cap washer
- 56. Pump head cap ring
- 57. Pump head cap nut
- 58. Pump head cap washer
- 59. Pump head cap ring
- 60. Pump head cap nut
- 61. Pump head cap washer
- 62. Pump head cap ring
- 63. Pump head cap nut
- 64. Pump head cap washer
- 65. Pump head cap ring
- 66. Pump head cap nut
- 67. Pump head cap washer
- 68. Pump head cap ring
- 69. Pump head cap nut
- 70. Pump head cap washer
- 71. Pump head cap ring
- 72. Pump head cap nut
- 73. Pump head cap washer
- 74. Pump head cap ring
- 75. Pump head cap nut
- 76. Pump head cap washer
- 77. Pump head cap ring
- 78. Pump head cap nut
- 79. Pump head cap washer
- 80. Pump head cap ring
- 81. Pump head cap nut
- 82. Pump head cap washer
- 83. Pump head cap ring
- 84. Pump head cap nut
- 85. Pump head cap washer
- 86. Pump head cap ring
- 87. Pump head cap nut
- 88. Pump head cap washer
- 89. Pump head cap ring
- 90. Pump head cap nut
- 91. Pump head cap washer
- 92. Pump head cap ring
- 93. Pump head cap nut
- 94. Pump head cap washer
- 95. Pump head cap ring
- 96. Pump head cap nut
- 97. Pump head cap washer
- 98. Pump head cap ring
- 99. Pump head cap nut
- 100. Pump head cap washer




Figure 3-17. Pump pressure relief valve adjustment.

3. Piping System

Refer to sheet 1 of figure 3-15 for three-way valve, removal and installation.

removal and installation.

b. Refer to figure 3-18 for shutoff valve




Fig. 3-18:

Assembly

nozzle


elbow

coupling

nut

head cap

bracket



b. Refer to item 21, figure 3-20, for tank pressure relief valve, removal and installation.

c. Refer to item 15, figure 3-21, for burner assembly, removal and installation; also, burner disassembly and reassembly.

d. Refer to item 17, figure 3-20, for fuel shutoff valve, removal and installation.


e. Refer to figure 3-20, item 10, for line Y-strainer,

f. For burner thermostatic control, removal and installation, refer to (1) thru (3), below.

(1) Refer to item 39, figure 3-21, for sensing element, removal and installation.


(2) Refer to items 8 and 4, figure 3-21, for gas and air line, removal and installation.

(3) Refer to item 43, figure 3-21, for burner thermostatic control, removal and installation.



- 37. Throttling valve
- 38. Machine cap screw
- 39. Thermal sensing element
- 40. Lock washer
- 41. Retaining plug clip
- 42. Hexagon head cap screw
- 43. Temperature control assembly
- 44. Binder head screw
- 45. Cover

- 46. Gasket
- 47. Brass nut
- 48. Brass ferrule
- 49. Copper tubing
- 50. Male adapter
- 51. Flat head screw
- 52. Relief valve
- 53. Controller mitg bracket



Section I. SHIPMENT AND LIMITED STORAGE

Preparation of Equipment for Shipment

General. When preparing the heating kettle for shipment, an inspection must be made to see that the kettle is in a good state of repair and can be put into immediate operation upon arrival.

Preparation.

Prepare the engine for shipment in accordance with the instructions in TM 5-2805-256-14.

Remove and separately pack the following components:

(a) Fuel hose assembly, spray hose, and spray gun assembly.

(b) Drawoff valve.

(c) Thermometer.

(d) Thermostatic control.

Clean all surfaces with an approved cleaning solvent and dry thoroughly.

Refer to the basic issue items list (appendix B). Items listed are on or with the heating kettle and in good serviceable condition.

Refer to TM 740-90-1 for preservation, packing, and shipping instructions.

Loading the Equipment for Shipment

Ramp Loading. Provide a suitable ramp at the rear of the carrier. Position the bitumen heating kettle on the bed of the carrier by means of another

Slings Loading. Attach slings to the two front and two rear lifting eyes. Use a suitable hoist and chain to lift the bitumen heating kettle to the bed of the car-

rier and secure the wires to the bed of the carrier.

4-3. Preparation of Equipment for Storage

a. Definition. Limited storage is defined as storage for a period not to exceed 6 months.

b. Inspection. Make a complete inspection of the bitumen heating kettle as described in paragraph 4-2. Correct or report all discrepancies noted during inspection and maintenance.

c. Preservation. Equipment in limited storage must be given only limited preservation as specified in paragraph 4-2. In addition, the following operations will be performed:

(1) **Cleaning and drying.** Prior to the application of any preservative or paint, thoroughly clean all surfaces to be coated with an approved cleaning solvent. Exercise care in cleaning so that the electrical circuits and components are not damaged. After cleaning, and before applying the preservative, all surfaces and parts will be thoroughly dried.

(2) **Painting.** Remove all rust, corrosion, and scale from the surfaces to be painted. Refer to TM 5-213 for detailed painting instructions.

(3) **Engine.** Refer to TM 5-2805-256-14 for instructions for preservation of the engine.

(4) **Tires.** Inflate the tires to 45 psi. Rack the carrier block the heating kettle so that no weight will be placed on the tires.

(5) **Weatherproofing.** A waterproof covering must be provided to protect the bitumen heating kettle if stored outside. Seal all openings such as the

equipment when equipment is initially placed in limited storage and every 30 days thereafter. Required maintenance will be performed promptly to

ings, gears, and so on, at least every 30 days. Equipment must be serviced and in satisfactory operating condition before it is operated.

Section II. DEMOLITION TO PREVENT ENEMY USE

5. General

When capture or abandonment of the bitumen heating kettle to an enemy is imminent, the responsible commander must make the decision either to destroy the equipment or to render it inoperative. Based on this decision, orders are issued which cover the desired extent of destruction. Whatever method of demolition is employed, it is essential to destroy the same vital parts of all heating kettles and all corresponding repair parts (TM 750-244-3).

6. Demolition to Render the Bitumen Heating Kettle Inoperative

a. Mechanical Means. Use sledge hammers, crow-bars, picks, axes, or any other heavy tools which may be available to destroy the following:

- (1) Engine block, gear reducer assembly, clutch assembly, and pump assembly.
- (2) Upper and lower three-way valves.
- (3) Thermostat bulbs, thermostats, gages, and pump assembly.
- (4) Tires.

Note. The above steps are minimum requirements for this method.

b. Misuse. Drain engine crankcase of all oil and fill with gravel, nuts, bolts, screws, or broken glass, to operate the power spray system.

Note. The above steps are the minimum requirements for this

(2) Place a ½-pound charge on the gear reducer assembly.

(3) Place a ½-pound charge between the air pressure tank and the outer shell.

(4) Place a ½-pound charge on the axle between the right wheel and frame assembly.

b. Weapons' Fire. Fire on the heating kettle with the heaviest practical weapons available.

4-8. Other Demolition Methods


a. Scattering and Concealment. Remove all accessible parts, such as the engine, three-way valves, gages, burner assembly, and spray bar assembly, scatter them through dense foliage, bury them in sand, and throw them in a lake, stream, or body of water.

b. Burning. Pack rags, clothing, or canvas around the unit. Saturate this packing with gasoline, oil, or diesel fuel, and ignite.

c. Submersion. Totally submerge the unit in a body of water to provide water damage and concealment. A body of salt water will do greater damage to metal parts than submersion in a body of fresh water.

4-9. Training

All operators should receive thorough training in the destruction of the heating kettle. Simulated destruction, using all the methods listed above, should be



LEGEND:

■ 1/2 POUND CHARGE

ME5-3895-334-15

Figure 4-1. Placement of charges.

Section I. GENERAL

1. Scope

The following instructions are provided for the use of field and depot maintenance personnel. They contain information on the maintenance of the equipment which is beyond the scope of the tools, equipment, personnel, or supplies normally available to organizational maintenance facilities.

Appendix A contains a list of all publications applicable to field and depot maintenance facilities

for this equipment. Appendix C contains the maintenance allocation chart. Appendix B contains the basic issue items list.

5-2. Forms and Records

DA Forms and procedures used for equipment maintenance will only be those prescribed by TM 5-2805-256-14 (Army Equipment Record Procedures).

Section II. DESCRIPTION AND DATA

1. Description

Refer to paragraph 1-3 for a complete description of the heating kettle.

5-4. Field and Depot Maintenance Tabulated Data

- Refer to TM 5-2805-256-14 for engine tabulated data.
- Refer to paragraph 1-6 for kettle tabulated data.

Section III. REPAIR PARTS, SPECIAL TOOLS AND EQUIPMENT

Special Tools and Equipment

Special tools or equipment are required to maintain or repair the heating kettle.

Direct Support, General Support, and Depot Maintenance Repair Parts

Direct support, general support, and depot main-

tenance repair parts are listed and illustrated in TM 5-3895-334-25P.

5-7. Specially Designed (Fabricated) Tools and Equipment

No specially designed tools or equipment are required to maintain or repair the heating kettle.

operate or operates im- properly	Spring impro- perly adjusted or broken.	(para. 5-19).
	b. Drive pin sheared.	b. Replace drive pin (para 5-19). Inspect gear and drive shaft for wear or damage, and replace if necessary.
	c. Gears worn or broken.	c. Replace gears (para. 5-19).
	d. Gasket defective.	d. Replace gasket (para. 5-19).
	e. Packing defective.	e. Replace packing (para. 5-19).
2. Clutch fails to operate or operates im- properly.	a. Worn or damaged shifter collar.	a. Replace shifter collar (para. 5-20).
	b. Worn or damaged wedge sleeve.	b. Replace wedge sleeve (para. 5-20).
	c. Lever rollers worn or damaged.	c. Replace lever rollers (para. 5-20).
	d. Driving plate worn or damaged.	d. Replace driving plate (para. 5-20).
3. Gear reducer fails to operate or operates im- properly.	a. Seal leaking lubricant.	a. Replace seal (fig. 5-1) (para. 5-12).
	b. Gasket leaking lubricant.	b. Replace gasket (fig. 5-1) (para. 5-12).
	c. Bearing damaged or worn.	c. Replace bearing (fig. 5-1) (para. 5-12).
	d. Gears damaged or worn.	d. Replace gears (fig. 5-1) (para. 5-12).

Section V. REMOVAL AND INSTALLATION OF MAJOR COMPONENTS AND AUXILIARY

5-9. Engine

Refer to TM 5-2805-256-14 for engine repair.

5-10. Fuel System

5-11. Electrical System

Refer to paragraph 3-23 for electric
removal and installation.

6. Leg Stands

Refer to paragraph 3-26 for leg stands, removal and installation.

5. Springs

Refer to figure 3-11 for spring, removal and installation.

6. Reflectors

Refer to paragraph 3-28 for reflector, removal and installation.

7. Thermometer

Refer to paragraph 3-24 for thermometer, removal and installation.

8. Pressure Gage

Refer to paragraph 3-30 for pressure gage, removal and installation.

9. Pump

Refer to paragraph 3-31 for pump, removal and installation. Disassemble and reassemble pump as shown by figure 3-16.

5-21. Fuel System

a. Refer to paragraph 3-35a for air pump, removal and installation. Refer to figure 3-20 for air pump disassembly and reassembly.

b. Refer to paragraph 3-35c for burner assembly, removal and installation. Refer to paragraph 3-35d for burner assembly, disassembly and reassembly.

c. Refer to paragraph 3-35g for thermostat, removal and installation.

d. Refer to paragraph 3-35b for pressure relief valve, removal and installation.

e. Refer to paragraph 3-34e for fuel shut-off valve, removal and installation.


5-22. Bitumen Piping System


Refer to figure 3-15, sheet 1, for piping and fittings, removal and installation.

5-23. Melt Tank

Refer to figure 5-3 for melt tank, removal and installation. Repair melt tank by welding or brazing.

Caution: Use a hoist or lifting device with a minimum 500-pound lifting capacity when removing and installing melt tank.





TANK LID

BOLT

BARREL RACKS

ELBOW

SIGHT GLASS

1. REMOVE ALL BOLTS
2. LINING TANK TOP.
3. APPLY HEAT TO REAR LIFT
4. REMOVE AND STRAIGHTEN
5. REMOVE BARREL RACKS
6. REMOVE INSIDE FLOW

Protection

00-200-10

Hand Portable Fire Extinguishers for Army Users

ation

L

05-256-12

Fuels, Lubricants, Oils and Waxes

95-334-12

Military Standard Engine Lubrication Order

Bituminous Kettle Lubrication Order

ing

3

Painting Instructions for Field Use

enance

370-1

Care and Maintenance of Pneumatic Tires

750

Army Equipment Record Procedures

305-256-14

Operator, Organizational, DS and GS Maintenance Manual, Military Standard Engine

305-256-24P

Organizational, DS and GS Maintenance Repair Parts and Special Tools Lists, Military Standard Engine

395-334-25P

Organizational, DS, GS, and Depot Maintenance Repair Parts and Special Tools List, Kettle, Heating, Bituminous

ment and Storage

-90-1

Administrative Storage of USAMEC Mechanical Equipment

-244-3

Procedures for Destruction of Equipment to Prevent Enemy Use

cope

appendix lists items which accompany the bituminous kettle or are required for installation, operation, or operator's maintenance.

General

The basic issue items list is divided into the following categories:

Basic Issue Items — Section II. A list of items which accompany the bituminous kettle and are required by the operator/crew for installation, operation, or maintenance.

Maintenance and Operating Supplies — Section III. Listing of maintenance and operating supplies required for initial operation.

Explanation of Columns

The following provides an explanation of columns in the Basic Issue Items list of Section II.

Source, Maintenance, and Recoverability Codes

Source code, indicates the listed item. Source code is:

Explanation

Repair parts which are stocked in or supplied from the GSA/DSA or Army supply system, and authorized for use at indicated maintenance categories.

Repair parts which are procured and stocked for insurance purposes because the combat or military essentiality of the end item dictates that a minimum quantity be available in the supply system.

Repair parts which are not procured or stocked, but are to be manufactured in indicated maintenance levels.

Assemblies which are not procured or stocked as such, but are made up of two or more units. Such component units carry individual stock numbers and descriptions, are procured and stocked separately and can be assembled to form the required assembly at indicated maintenance categories.

Parts and assemblies which are not procured or stocked and the mortality of which normally is below that of

Code

G- Major assemblies that are procured with PEM for initial issue only as exchange assemblies and GSU level. These assemblies will not be above DS and GS level or returned to depot level.

Explanation

(2) Maintenance code indicates the lowest category of maintenance authorized to install the item. The maintenance level code is:

Code

C

Explanation

Operator/crew

(3) Recoverability code, indicates whether serviceable items should be returned for recovery or salvage. Items not coded are expendable. Recoverability codes are:

Code

R

Explanation

Applied to Repair parts (assemblies and components) which are considered economically repairable at depot and general support maintenance levels. When maintenance capability to repair these items does not exist, they are normally disposed of at the depot level. When supply considerations dictate, some of these repair parts may be listed for automatic return to depot for depot level repair as set forth in AR 710-5-1. If so listed, they will be replaced by supply on an exchange basis.

S

Repair parts and assemblies which are economically repairable at DSU and GSU activities and which are normally furnished by supply on an exchange basis. Items are determined by a GSU to be uneconomically repairable they will be evacuated to a depot for inspection and analysis before final disposition.

T

High dollar value recoverable repair parts which are subject to special handling and are issued on an exchange basis. Such repair parts are normally repaired and hauled at depot maintenance activities.

U

Repair parts specifically selected for salvage because of precious metal content, rare materials, or high dollar value reusable castings.

b. **Federal Stock Number.** This column indicates the Federal stock number assigned to the item. This will be used for requisitioning purposes.

c. **Description.** This column indicates the Federal item name and any additional description of the

c. A "V" appearing in this column in lieu of a quantity indicates that a definite quantity cannot be stated (e.g., shims, spacers, etc.).

Quantity Furnished With Equipment. This column indicates the quantity of an item furnished with equipment.

Illustration. This column is divided as follows:

(1) **Figure Number.** Indicates the figure number of the illustration in which the item is shown.

(2) **Item Number.** Indicates the callout number to reference the item in the illustration.

Explanation of Columns in the Tabular of Maintenance and Operating Supplies—Section III

Component Application. This column identified component application of each maintenance or

c. **Description.** This column indicates the name and brief description.

d. **Quantity Required for Initial Operation.** This column indicates the quantity of each maintenance and operating supply item required for initial operation of the equipment.

e. **Quantity Required for 8 Hours' Operation.** This column indicates the estimated quantities required for an average 8 hours of operation.

f. **Notes.** This column indicates informative data keyed to data appearing in a preceding column.

B-5. Federal Supply Code for Manufacturers

Code	Manufacturer
03742	Midwest Tank and Mfg. Co.

Section II. BASIC ISSUE ITEMS

(2) Federal stock No.	(1) Description Ref No. & Mfr code	(4) Unit of meas	(5) Qty inc in unit	(6) Qty furn with equip	(7) Illustration	
					(A) fig No.	
	DA TECHNICAL MANUAL TM 5-3895-334-15	EA		1		
	DA TECHNICAL MANUAL TM 5-2805-256-14	EA		1		
	DA LUBRICATION ORDER LO 5-2805-256-12	EA		1		
	DA LUBRICATION ORDER LO 5-2805-256-12					

	(2) Federal Stock number	(3) Description	(4) Quantity required /initial operation	(5) Quantity required /75 hrs operation	(1) See C910 and requisition (2) See current and replenishment (3) Average gal per hour of (4) Burner operation is 5 gal per operation.
lubri- LO -12	9130-160-1818(1) 9140-286-5288(2)	FUEL, GASOLINE: Automotive: Bulk as follows: 91A Grade DIESEL FUEL: 55-gal drum as follows: DF-1	1½ gal 20 gal	6 gal (3) 40 gal (4)	
r	9150-265-9433 9150-265-9425	OIL, LUBRICATING: 1-qt can as follows: OE-30 OE-10	6/8 qt 6/8 qt	(2) (2)	
s	9150-190-0904(2) 9150-261-8287(2)	GREASE, AUTOMOTIVE AND ARTILLERY: 1-lb can as follows: GAA ¼-in. dia stick	1 box	(2)	

Section I. INTRODUCTION

General

This section provides a general explanation of maintenance and repair functions authorized at maintenance levels.

Section II designates overall responsibility for performance of maintenance functions on the end item or component. The implementation of the maintenance functions upon the end item or component will be consistent with the assigned maintenance functions.

Section III lists the special tools and test equipment required for each maintenance function as indicated from section II.

Section IV contains supplemental instructions, cautionary notes and/or illustrations required for each maintenance function.

Explanation of Columns in Section II

Assembly Group Number, Column (1). The assembly group number is a numerical group assigned to each assembly in a breakdown sequence. The applicable assembly groups are listed on the MAC (Maintenance Action Chart) in disassembly sequence beginning with the first assembly removed in a top-down disassembly sequence.

Assembly Group, Column (2). This column contains a brief description of the components of each assembly group.

Maintenance Functions, Column (3). This column lists the various maintenance functions (A through K) and indicates the lowest maintenance level authorized to perform these functions. The symbol designations for the various maintenance functions are as follows:

C — Service. To clean, to preserve, to change, to add fuel, lubricants, cooling agents, and so on. If it is desired that elements, such as painting and sandblasting, be defined separately, they may be so listed.

D — Adjust. To rectify to the extent necessary to bring into proper operating range.

E — Align. To adjust specified variable elements of an item to bring to optimum performance.

F — Calibrate. To determine the correction necessary made in the readings of instruments or test equipment used in precise measurement. Consists of comparison of two instruments, one of which is a certified standard of known accuracy, to determine and adjust any discrepancy in the accuracy of the instrument being compared with the standard.

G — Install. To set up for use in an operating environment such as an emplacement, site, or vehicle.

H — Replace. To replace unserviceable items with serviceable like items.

I — Repair. Those maintenance operations necessary to restore an item to serviceable condition through correction of material damage or a functional failure. Repair may be accomplished at each level of maintenance.

J — Overhaul. Normally, the highest degree of maintenance performed by the Army in which the minimum time work in process is consistent with quality and economy of operation. It consists of maintenance necessary to restore an item to fully serviceable condition as prescribed by maintenance standards in technical publications for each type of equipment. Overhaul normally does not result in an item to like new, zero mileage, or zero hour condition.

K — Rebuild. The highest degree of mater-

C-3. Explanation of Columns in Section III

a. *Reference Code.* This column consists of a number and a letter separated by a dash. The number references the T&TE requirements column on the MAC. The letter represents the specific maintenance function the item is to be used with. The letter is representative of columns A through K on the MAC.

ber of tools and test equipment.

a. *Reference Code.* This column letters separated by a dash, both of references to section II. The first letter references (5) and the second letter references function, column (3), A through K.

Section II. MAINTENANCE ALLOCATION CHART

(1) Group No.	(2) Functional group	(3) Maintenance functions										To equ
		A	B	C	D	E	F	G	H	I	J	
		Inspect	Test	Service	Adjust	Align	Calibrate	Install	Replace	Repair	Overhaul	
01	ENGINE											
0100	Engine Assembly											
	Engine, gasoline	C	O	C	C				O	F		
03	FUEL SYSTEM											
0306	Tank, Lines, Fittings											
	Cap, fuel tank	C							C			
	Lines, fuel	C							O			
0309	Fuel Filters	C							O			
06	ELECTRICAL SYSTEM											
0609	Head, Tail & Marker Lights,											
	Lamp Bulb								O			
	Lamp assembly, tail &											
	marker	C							O			
0613	Hull or Chassis Wiring											
	Harness								O	O		
	Trailer coupling cable	C							O			
08	POWER TRANSFER											
0800	Power Transfer, AY								O			

	Inspect	Test	Survive	Adjust	Align	Calibrate	Install	Replace	Repair	Overhaul	Rebuild
Output Shaft, Main Shaft											
Bearings	F							F			
Gaskets & seals	F							F			
Gear & shaft	F							F			
WHEELS AND TRACKS											
Wheel Assembly	C							O			
Cup & cone bearings	O			O				O			
Seals, grease	O							O			
Tires, Tubes	C		C					O	O		
FRAME											
Pintles and Towing											
Attachments											
Safety chain											
Landing Gear; Leveling											
Jacks				C				O			
Pin, height adjustment								O			
SPRINGS & SHOCK											
ABSORBERS											
Rear Springs	O							F			
Bolt, shackle	O		O					O			
MISCELLANEOUS BODY											
HULL & ACCESSORY											
ITEMS											
Mirrors, Reflectors,											
Personnel Heaters,											
Defrosters, Wipers, Air-											
horn, Reflector											
Assembly	O							O			
GAGES (NON-ELECTRICAL)											
WEIGHING & MEASURING											
DEVICES											
Temperature Gages											
Thermometer	C							O			
Pressure Gages											
Gage, pressure, dial											
indicating	C							O			
PUMPS (EXCLUDE ENGINE											
PUMPS)											
Pump Assembly			C					O	F		
Gasket, housing								O			
Valve, pressure relief	C							F			

	Inspect	Test	Service	Adjust	Align	Calibrate	Install	Replace	Repair	Overhaul	Rebuild
Fuel Tank											
Pump assembly air			C					O	O		
Thermostat, operating & safety		O	O					O			
Hose assembly								O			
Regulator, pressure			O	C				O			
Valve, relief pressure			O					O			
Valve, assembly, safety	C							O			
Line, air	C							O			
Pipe and fittings	C							O			
Valve, fuel shutoff			C					O			
Fuel tank			C					O			
Cap assembly, fill			C					C			
CONCRETE & ASPHALT EQUIPMENT											
(Mixers; Pavers; Spreaders; Finishers, etc.)											
Material Spray Bar			C					O	O		
Coupling, quick action	C							O			
Cock	C							O			
Nozzle, spray			C					C			
Tanks, Valves, etc.			C						F		
Link, fusible	C							O			
Valve, three-way Lower			C					O			
Valve, three-way upper			C					O			
Valve, pressure relief				O				O	O		
Pipe and fittings	C							O			
Shell assembly furnace									F		
Vat, melting	O		C					H	F		
Coupling, quick action	C							O			
Hose, spray	C							O			

Section III. SPECIAL TOOL AND SPECIAL TEST EQUIPMENT REQUIREMENTS

Reference code	Maintenance category	Nomenclature	Tool number
	C	Cleaning Needle	TK-002 (0374)

Section IV. REMARKS

	Paragraph	Page
A		
ment:		
ings, wheel	3-25	3-19
ch assembly	3-24	3-14
f valve	3-31	3-25
mostatic control	2-11, 3-35	2-9, 3-19
es	3-35	3-32
	3-25	3-19
B		
ut lamp assembly lamp replacement	3-23	3-8
r assembly	3-35	3-32
fuel hose assembly	3-35	3-32
system components:		
er fuel tank and hand pump assembly	3-35	3-32
eral	1-3	1-1
ty valve assembly, fuel tank cap, gages and air lines	3-35, 5-21	3-32, 5-4
mostat	1-3, 2-11, 3-35	1-1, 2-9
C		
	3-23	3-8
ties, data	1-3, 1-6	1-1, 1-4
, safety	2-4	2-4
s and running gear components:		
eral	1-3	1-1
s	3-25	3-19
ling stand, pins, and chains	3-26	3-23
ty chains	2-4	2-4
ngs, axle, and fittings	3-27	3-24
assembly	3-24, 5-20	3-14, 5-4
assembly adjustment	3-24	3-14
ponents, engine and (see engine and components)		
ls and instruments	2-7	2-4
ng	3-24	3-14
ng assembly	3-24	3-14
D		
tabulated (see tabulated data)		
ition:		
xplosives or weapons' fire	4-7	4-2
eral	4-5	4-2
er methods	4-8	4-2
ender bitumen heating kettle inoperative	4-6	4-2
ning	4-9	4-2
ption	1-3	1-1
ences in models	1-5	1-4
sions and weights, data	1-6	1-4
E		

Special tools	3-1
Unloading	2-1
Unpacking new	2-1

F

Field and depot maintenance record and report forms	5-2
Field and depot maintenance troubleshooting (see troubleshooting, field and depot maintenance)	
Field and depot maintenance tabulated data (see tabulated data, field and depot maintenance)	
Field expedient repairs	3-21
Forms, record and report	5-2
Fuel tank burner	3-35
Fuel tank cap	3-33
Fuel tank, fuel tank cap, and fuel line	3-35
Fusible link	3-34

G

Gages	2-7, 2-2
Gear reducer assembly	5-12

H

Hand pump assembly	5-21
Hose	3-25
Hubs	3-15

I

Identification	1-4
Inspection and maintenance of equipment in storage	4-3
Inspection of new and used equipment	3-6
Installation and setting-up instructions	2-3
Instruments and controls	2-7

K

Kettle system components:

Fusible link	3-34
General	1-3
Stack	1-3
Tank cover	3-34
Thermometer	3-29

L

Lamp:

Blackout	3-26
Stoplight-taillight	3-26

Leveling stands, pins, and chains	3-26
-----------------------------------	------

Lighting system components:

General	3-23
Reflector assembly	3-28
Stoplight-taillight and blackout lamp assembly lamp replacement	3-23
Stoplight-taillight, blackout lamp assembly and strap	3-23
Wiring harness, cable, and strap	3-23

Lines, air	3-35
------------	------

Link:

Fusible	3-34
---------	------

er areas	2-16	2-18
ny or humid conditions	2-15	2-18
al conditions	2-8	2-9
d organizational maintenance record and report forms	5-2	5-1
d organizational maintenance troubleshooting (see troubleshooting)		
d organizational tabulated data (see tabulated data)		
aily services	3-8	3-5
al maintenance	3-1	3-1
P		
	3-26	3-23
	3-32	3-29
system components:		
sembly adjustment	3-24, 5-20	3-14, 5-4
	3-24	3-14
cer, clutch, and pump assemblies	3-12, 3-24, 3-31	3-5, 3-14, 3
	3-31	3-25
ee-way valve and piping	3-32	3-29
ve	3-31	3-25
ve adjustment	3-31	3-25
	3-24, 5-20	3-14, 5-4
assembly and hose	3-33	3-29
ee-way valve and piping	3-32	3-29
system maintenance instructions:		
sembly	3-24, 5-20	3-14, 5-4
	3-22, 5-9	3-8, 5-2
cer assembly	5-12	5-2
sembly	3-32	3-29
of equipment for shipment	4-2	4-1
of equipment for storage	4-3	4-1
ief valve	3-22	3-8
maintenance services:		
	3-5	3-2
s daily services	3-7, 3-8	3-5
ional maintenance	3-11	3-5
blies	3-22	3-8
bly, air	3-25	3-19
R		
r	5-12	5-2
sembly	3-18	3-5
ressure	3-25	3-19
	3-22	3-8
adjustment	3-22	3-8
r components	3-15	3-5
S		
s	2-4	2-4
assembly, relief valve, pressure regulator, fuel tank cap,		
air lines	2-2, 2-7, 3-35	2-1, 2-4, 3-3
	1-1, 5-1	1-1, 5-1
	1-2	1-1

Storage:	
Inspection and maintenance of equipment	4-3
Preparation of equipment	4-3
Strap	3-23
	T
Tabulated data, field and depot maintenance:	
Engine	1-6
Tabulated data, operator and organizational:	
Capacities	1-6
Dimensions and weights	1-6
Engine	1-6
General	1-6
Pump assembly	1-6
Reducer gear	1-6
Transportation and tiedown plates	1-6
Wiring diagram	1-6
Tank cover	2-15
Tank, melting	1-36
Thermometer	3-29
Thermostat	3-36
Training, demolition	4-9
Transportation and tiedown plates, data	1-6
Troubleshooting, operator and organizational maintenance:	
Field expedient repairs	3-21
	U
Unloading of equipment	2-1
Unpacking new equipment	2-1
Upper three-way valve and piping	3-23
	V
Valve:	
Relief	3-32
Three-way, lower	3-32
Three-way, upper	3-32
Valve assembly, safety	3-35
	W
Wheels	3-25
Wiring diagram	1-6
Wiring harness, cable, and straps	3-23

W. C. WESTMORELAND
General, United States Army
Chief of Staff.

ETH G. WICKHAM,
General, United States Army,
Adjutant General.

on:
e distributed in accordance with DA Form 12-25, Section II (qty rqr block no. 421), Operator's r
uirements for Heaters, Bituminous.

☆ U. S. GOVERNMENT PRINTING OFFICE : 1989 O - 242-451 (16